



## LCM1502TV Troubleshooting Guide

### Poor TV Reception

- Verify auto programming of the tuner is preformed.
- Verify condition of antenna.
- Verify tuning into a strong station in your area.
- Verify antenna coax cable is connected to TV.
- Look for any breaks in the antenna or coax cable.
- Verify cable connections are not loose or shorting out.
- Replace with known good antenna.

Due to the nature of TV signals, vehicle motion, direction the vehicle is facing, distance from the TV transmitter, nearby surroundings and weather may adversely effect TV reception. Results of these conditions may be picture roll, poor reception (snowy picture), and momentary loss of color (especially while the vehicle is in motion). For best viewing results, this antenna system is recommended to be used while the vehicle is stationary.

### Poor Audio

- Verify patch cable is firmly connected between LCM1502TV and your sound system and in good condition.
- If using a FM modulator, verify it is properly connected and operating normally.
  - FM modulator may be set to a frequency in use in your area. Try a different frequency.

### No Power to LCD

- Verify +12VDC on red wire at power harness going to the video pod.
- Verify ground connection.

### Power but no Video or Sound

- Verify connections at both ends of source component harness.

### IR Sensor inoperative

- Verify that the batteries in the remote are fresh.
- Verify that the remote eye is not obstructed.
- Verify that the infrared transmitter is affixed over the sensor eye of the component to be controlled.